





Flag hoisting guide




Rope & Toggle



Inglefield Clips




Eyelets



Sleeve & Eyelets

Note: The flagpole must be lowered in order to slide the flag sleeve onto the rotating arm.



DO NOT FLY YOUR FLAG IN STORM OR GALE CONDITIONS